

**ATV Calf Catcher Sizing Guide for Front Bumper Mount**

**(A)** Measure the length from the front of the front bumper to the center of the rear ball. The simplest method to get this dimension is as follows;

1. Back the ATV against a wall.
2. Measure from the wall to the front of the front bumper.
3. Measure from the wall to the center of the rear ball.
4. Subtract dimension 3 from dimension 2. This gives you the dimension needed.

This model fits from 72" to 84 7/8".

**(B)** Measure from the ground to the center of the rear ball.

This model fits from 10 3/8" to 15 3/8".

**(C)** Measure from the ground to the bottom of the front bumper.

This model fits from 31 5/8" to 37 1/2".

**(D)** Measure the width of the ATV and divide by 2.

This model fits ATV's up to 56" wide.

**(E)** Measure the width of the ATV and divide by 2. Add this dimension to 98 1/4" and you have the total width of the Calf Catcher attached to the ATV. Good for checking if it fits through fence line gates.

Custom hitches can be made for ATV's that do not fit within these standard model dimensions.

