

lakeland

FARM & RANCH DIRECT

PRODUCT INSTALL MANUAL



DUTCH WINDOWS



Premium Products, Premium Service...Direct to Your Door!

Canada Office: Box 1310, 1 Limestone Drive, Stonewall, Manitoba, Canada, R0C 2Z0

US Office: 2700 Alliance Drive, Waterford, MI 48328

Ph: (204) 467-4470 | Tf: 1-866-443-7444

LakelandFarmandRanch.com

1. Install the jamb by sliding it into the framed window opening. Use shims to space the jamb evenly within the opening, making sure it remains square. Check that the jamb is plumb vertically, then secure it in place using 3-inch structural screws.

2. To install the window, locate the stainless steel hinges, 4-inch bolts, and acorn nuts in the hardware box. Attach the stainless steel hinges to the tabs on the jamb using the 4-inch bolts.

Next, remove the first nut and washer from both hinges. This next step will require two people. Carefully lift the window and guide the stainless steel hinge threads through the large tabs on the window. Once the window is in place, reinstall the washers and nuts and tighten them securely.

If you are using weather stripping, this is also the best time to apply it to the window stop.

Head Office: Box 1310, 1 Limestone Drive, Stonewall, Manitoba, Canada, R0C 2Z0

US Office: 2700 Alliance Drive, Waterford, MI 48328

Ph: (204) 467-4470 | Fx: 1-855-483-2953 | Tf: 1-866-443-7444

LakelandFarmandRanch.com

3.

To finish the window, locate the spring latch pin and spring in the hardware box. Remove the handle, insert the plunger pin into the spring latch body, then place the handle into the slot above. Turn the plunger clockwise until it is securely fastened.



Next, close the window and make sure it sits flat against the window stop. Tighten the hinges as needed. Finally, position the stainless steel catch plate in the desired location and secure it using the self-tapping screws.

