

lakeland

FARM & RANCH DIRECT

ASSEMBLY INSTRUCTIONS for WORKING CHUTE & CROWDING TUB

for Sheep & Goats (WCCT-DX System)



Your Ideas, Our Products... Better Together.



Thank you!


Thank you for purchasing a Lakeland Working Chute & Crowding Tub (WCCT-DX), for your sheep or goats. Please read this manual to find out how your WCCT-DX system assembles together!



lakeland

FARM & RANCH DIRECT

Your Ideas, Our Products...Better Together.



KEY:

WCT-DX- 2x Curved Crowding Panels, 1x 5ft Swing/Slide Door, 1x Straight Section w/ Alley entrance, 1x Curved Panel, 2x ground support bars.


WSP-DX- 4x 8' Long Straight Panels with Plastic sides. Drop Down bars.

WUS- 1x Alley Support

WGG- 1x Guillotine Gate

WAB- 1x Anti-backup Gate (can be placed anywhere in alley)

● = Pin



Please view following pictures to see how crowding tub assemblies.



1. Place “swing n slide” door circular plate over top of circular plate that is attached to the straight crowding tub section. (This piece also has the alley entrance included in it.)

lakeland

FARM & RANCH DIRECT

Your Ideas, Our Products...Better Together.



2. Unbolt 2x bolts which are on straight section of crowding tub. Slide along rail until cylinder piece slides over top of cylinder piece on the top of the swing n slide door. As per above picture. Firmly tighten bolts. Ensure door swings and slides freely around crowding tub.

lakeland

FARM & RANCH DIRECT

Your Ideas, Our Products...Better Together.



3. Next install the ground support bars as per left picture. 1x T-shaped bar and 1x L-shaped bar. L-shaped bar supports one end of the curved panel.

4. The T part of the center bar sits behind the 2x curved crowding tub panels as per right picture.



5. Insert both other ends into the center round plate of the swing door and tighten bolts.

6. Install “bugle” piece of crowding tub. See below picture.



7. Upon completion of crowding tub section, below is what should look like fully assembled.



Alley Adjustment

8. Pull up pin and push in bottom of alley panel to form a V alley. Replace pin in selected pin hole.



Alley adjusted to full width.

Alley adjusted half way in.



Alley adjusted to smallest width.



lakeland

FARM & RANCH DIRECT

Your Ideas, Our Products...Better Together.

Drop Down Sides on Alley

Lift up bar on top of alley panel and drop down towards ground. As per below pictures.




lakeland

FARM & RANCH DIRECT

Your Ideas, Our Products...Better Together.

P: 1-866-443-7444

***CONGRATULATIONS! YOU HAVE FINISHED
ASSEMBLING THE WCCT SYSTEM!***




lakeland

FARM & RANCH DIRECT

Your Ideas, Our Products...Better Together.

PIN ON OPTIONS AVAILABLE.


P: 1-866-443-7444



lakeland

FARM & RANCH DIRECT

Your Ideas, Our Products...Better Together.



lakeland

FARM & RANCH DIRECT

*Thank you for your
business!*

Contact Us:

Toll Free: 1-866-443-7444

Fax: 1-855-483-2953

E-Mail: info@lakelandgroup.net

Website: www.lakelandfarmandranch.com

Mailing Address:

Head Office: Box 1310, 1 Limestone
Dr., Stonewall, MB R0C 2Z0

US Office: 14250 Judicial
Road, Burnsville, MN 55306



Your Ideas, Our Products...Better Together.

